



Hardware Included:
 8 - Black Tie Wraps
 5 - Self Tapping Screws
 1 - Allen Wrench
 1 - Switch Mounting Bracket
 1 - Wiring Harness
 1 - Switch
 2 - Light Units

Installation Instructions:

1. Find and mount the switch bracket (A) in a suitable location or utilize an existing location for mounting the switch. Then press the switch into the chosen mounting location until it is fully seated.
 Bad Boy recommends placing the switch bracket on the upper rear bolt used to hold on the left hand tank (behind the brake) on ZT and CZT, or to use the plugged slot on the left hand side of the seat bracket (forward of the brake) on Outlaws and Diesels.
2. Choose the desired location to mount the light units (B). Then remove the brackets (C) from the lighting units. Check the desired location to make sure that the light units will not interfere with any functionality of the mower.
 Bad Boy recommends mounting the lights on the underside of the front rail of the frame.
3. Run the wiring harness along the frame rail. Then check to make sure the harness will reach the lights, switch, and battery. Bad Boy recommends using the left hand frame rail on ZT and CZT, and the left hand inner frame rail on Outlaws and Diesels.
4. Use the brackets to mark the location where the included self-tapping bolts (D) will be used to mount the brackets to the mower.
5. Drill a small pilot hole (One smaller than the diameter of the thread on the self-tapping bolts) at the marked location.
6. Use the included self-tapping bolts (D) to secure the light unit brackets to the mower.
7. Reassemble the light units.
8. Loosely zip tie the harness to the chosen frame rail. Starting from the lights.
9. Route the remaining harness under the seat and connect the positive then the negative ends of the harness to the battery. Keep harness away from any moving parts and any pinch points that could damage the harness.
10. Connect the harness to the light units then to the switch.
11. Starting at the front of the mower tighten and trim the zip ties. Make sure that there is enough slack around the connections to the lights and that there is minimal slack in the harness along the frame rail.
12. Check to make sure that the harness is away from all moving parts and pinch points then secure the remainder of the harness with zip ties. Trim zip ties as you go.

On MZ & MZ Magnum models use your own discretion on mounting of light kits.

If you require any additional assistance with mounting please call our technical hotline at (870) 698-0090.